

European Version



LEFT ←





Scandinavian Version



LEFT ←


Door directions
with left handle version

The handle with the RFID
reader function points to
the left



Door directions
with right handle version

The handle with the RFID
reader function points to
the right



European Version



→ RIGHT



Scandinavian Version



→ RIGHT